

Liquid Nanoparticle Ion Source (LNIS)


Boubakar Diallo, Sean McInnis, Jatin Mukerji

Mentor: Alex Hagen

Meet the Team



Jatin Mukerji B.S. '25,
M.Eng. '26
BEE




Sean McInnis
B.S. '26
ChemE



Boubakar Diallo
B.S. '28
ECE



Alex Hagen
Team Mentor




Stefan Bell
Primary Inventor

Useful Acronyms

- **LNIS**: Liquid **N**anoparticle **I**on **S**ource.
- **NIM**: **N**ano**I**onic **M**aterial
- **EMI-BF₄**: 1-**E**thyl-3-**m**ethyl**i**midazolium tetrafluoroborate, a room temperature ionic liquid widely used as an electrolyte in electrochemical studies.

Technology Overview



- Creating a better liquid “fuel” for microthrusters and electrospray analysis.
- Charged **NIMs** are extruded through a charged nozzle.
- Each satellite would have hundreds or thousands of these microthrusters.

Inventiveness Analysis

Invention Description

The Liquid Nanoparticle Ion Source (LNIS) provides an ion beam consisting of inherently charged nanoparticles emitted from a neat fluid, similar to an ionic liquid, released via electrostatic evaporation. This fluid exhibits low vapor pressure and room-temperature fluidity while maintaining a stable, high mass-to-charge species. The efficacy of this fluid is characterized by exposed surfaces and secondary species created as a result of the impacts from nanoparticles. In-situ current measurements of the nanoparticle beam identified multiple emission sites with narrow divergence. The NIMs fluid has vastly lower ionic conductivity than ionic liquids, but broadly has similar properties to ionic liquids. Diameters for both the trenches and craters indicate impacts that are highly energetic in nature. The detection of secondary species also demonstrates the ability of the nanoparticle ion beam to ionize ionic liquid material on the surface of a substrate. The NIMs class provides an easily-tunable mass-to- charge ratio which enables engineers to directly tune thruster performance characteristics for mission demands or adjust parameters for microscopy applications.

Invention Description

The Liquid Nanoparticle Ion Source (LNIS) provides an **ion beam** consisting of inherently charged nanoparticles emitted from a neat fluid, similar to an ionic liquid, released via electrostatic evaporation. This fluid exhibits low vapor pressure and room-temperature fluidity while maintaining a stable, high mass-to-charge species. The efficacy of this fluid is characterized by **exposed surfaces and secondary species created** as a result of the impacts from nanoparticles. In-situ current measurements of the nanoparticle beam identified multiple emission sites with **narrow divergence**. The NIMs fluid has vastly lower ionic conductivity than ionic liquids, but broadly has similar properties to ionic liquids. Diameters for both the trenches and craters indicate impacts that are highly energetic in nature. The detection of secondary species also demonstrates the ability of the nanoparticle ion beam to ionize ionic liquid material on the surface of a substrate. The NIMs class provides an easily-tunable mass-to-charge ratio which enables engineers to directly tune thruster performance characteristics for mission demands or adjust parameters for microscopy applications.

Prior Art Search

KR '79B1: Etching, secondary species formation, focused ion beam.

Invention Description

The Liquid Nanoparticle Ion Source (LNIS) provides an **ion beam** consisting of inherently charged nanoparticles emitted from a neat fluid, **similar to an ionic liquid**, released via electrostatic evaporation. This fluid exhibits low vapor pressure and room-temperature fluidity while maintaining a stable, high mass-to-charge species. The efficacy of this fluid is characterized by **exposed surfaces and secondary species created** as a result of the impacts from nanoparticles. In-situ current measurements of the nanoparticle beam identified multiple emission sites with **narrow divergence**. The NIMs fluid has vastly lower ionic conductivity than ionic liquids, but **broadly has similar properties to ionic liquids**. Diameters for both the trenches and craters indicate impacts that are **highly energetic in nature**. The detection of secondary species also demonstrates the ability of the nanoparticle ion beam to **ionize ionic liquid material** on the surface of a substrate. The NIMs class provides an easily-tunable mass-to-charge ratio which enables engineers to directly tune thruster performance characteristics for mission demands or adjust parameters for microscopy applications.

Prior Art Search

KR '79B1: Etching, secondary species formation, focused ion beam.

US '05B1: Ionization of a species in aerosol particles, charged droplets carrying dissolved contents of aerosol particles.

Invention Description

The Liquid Nanoparticle Ion Source (LNIS) provides an **ion beam** consisting of inherently charged nanoparticles emitted from a neat fluid, **similar to an ionic liquid**, released via **electrostatic evaporation**. This fluid exhibits low vapor pressure and room-temperature fluidity while maintaining a stable, high mass-to-charge species. The efficacy of this fluid is characterized by **exposed surfaces and secondary species created** as a result of the impacts from nanoparticles. In-situ current measurements of the nanoparticle beam identified multiple emission sites with **narrow divergence**. The NIMs fluid has vastly lower ionic conductivity than ionic liquids, but **broadly has similar properties to ionic liquids**. Diameters for both the trenches and craters indicate impacts that are **highly energetic in nature**. The detection of secondary species also demonstrates the ability of the nanoparticle ion beam to **ionize ionic liquid material** on the surface of a substrate. The NIMs class provides an **easily-tunable mass-to-charge ratio** which enables engineers to directly tune thruster performance characteristics for mission demands or adjust parameters for microscopy applications.

Prior Art Search

KR '79B1: Etching, secondary species formation, focused ion beam.

US '05B1: Ionization of a species in aerosol particles, charged droplets carrying dissolved contents of aerosol particles.

US '73B2 & '9907, JP '74B2: Electrospray ion source, selective adjustment of charge-state distribution.

Invention Description

The Liquid Nanoparticle Ion Source (LNIS) provides an **ion beam** consisting of inherently charged nanoparticles emitted from a neat fluid, **similar to an ionic liquid**, released via **electrostatic evaporation**. This fluid exhibits low vapor pressure and room-temperature fluidity while maintaining a stable, high mass-to-charge species. The efficacy of this fluid is characterized by **exposed surfaces and secondary species created** as a result of the impacts from nanoparticles. In-situ current measurements of the nanoparticle beam identified multiple emission sites with **narrow divergence**. The NIMs fluid has vastly lower ionic conductivity than ionic liquids, but **broadly has similar properties to ionic liquids**. Diameters for both the trenches and craters indicate impacts that are **highly energetic in nature**. The detection of secondary species also demonstrates the ability of the nanoparticle ion beam to **ionize ionic liquid material** on the surface of a substrate. The NIMs class provides an **easily-tunable mass-to-charge ratio** which enables engineers to directly tune thruster performance characteristics for mission demands or adjust parameters for microscopy applications.

Prior Art Search

KR '79B1: Etching, secondary species formation, focused ion beam.

US '05B1: Ionization of a species in aerosol particles, charged droplets carrying dissolved contents of aerosol particles.

US '73B2 & '9907, JP '74B2: Electrospray ion source, selective adjustment of charge-state distribution.

TW '063A: Ion source, “nanoparticle produces a square source of the ion source” through heating.

Invention Description

The Liquid Nanoparticle Ion Source (LNIS) provides an ion beam consisting of inherently charged nanoparticles emitted from a neat fluid, similar to an ionic liquid, released via electrostatic evaporation. This fluid exhibits low vapor pressure and room-temperature fluidity while maintaining a stable, high mass-to-charge species. The efficacy of this fluid is characterized by exposed surfaces and secondary species created as a result of the impacts from nanoparticles. In-situ current measurements of the nanoparticle beam identified multiple emission sites with narrow divergence. The NIMs fluid has vastly lower ionic conductivity than ionic liquids, but broadly has similar properties to ionic liquids. Diameters for both the trenches and craters indicate impacts that are highly energetic in nature. The detection of secondary species also demonstrates the ability of the nanoparticle ion beam to ionize ionic liquid material on the surface of a substrate. The NIMs class provides an easily-tunable mass-to-charge ratio which enables engineers to directly tune thruster performance characteristics for mission demands or adjust parameters for microscopy applications.

Prior Art Search

KR '79B1: Etching, secondary species formation, focused ion beam.

US '05B1: Ionization of a species in aerosol particles, charged droplets carrying dissolved contents of aerosol particles.

US '73B2 & '9907, JP '74B2: Electrospray ion source, selective adjustment of charge-state distribution.

TW '063A: Ion source, “nanoparticle produces a square source of the ion source” through heating.

Analysis of Technical Articles


Conferred Advantages

More stable

Property	NIMs, 15 nm	EMI-BF ₄
Surface Tension (N/m)	24	45
Ionic Conductivity (mS/m)	1	1200
Viscosity at 25°C (Pa·s)	0.2	0.0346
Storage Modulus (Pa)	0.07	~0.01
Loss Modulus (Pa)	1.3	~0.218
Dissipation Factor	20	>200
Vapor Pressure (Pa)	0.1	1.4

Lower conductivity → higher stability

Analysis of Technical Articles



Conferred Advantages

More stable

More modular

Species	Voltage (kV)	Average Exposure Current (pA)	Exposed Charge (pA-hr)	Energy Dose (nA-eV-hr)
NIM	-3, -3, -3	19, 29, 36	86, 120, 72	300, 420, 250
Jeffamine	3, 3, 3	34, 54, 65	85, 94, 170	8.5×10^{-2} , 9.4×10^{-2} , 0.17
EMI ⁺ , BF ₄ ⁻	3, -3	1.4×10^5 , 2.6×10^5	3.4×10^5 , 3.9×10^5	340, 390

“Solute”

“Solvent”

Property	NIMs, 15 nm (negative)	Jeffamine M600 (positive)	EMI ⁺	BF ₄ ⁻
Average mass (Da)	2.5×10^6	600	111	87
Average charge per ion (e)	3500	1	1	1
q/m (C/kg)	1.4×10^5	1.6×10^5	8.6×10^5	1.1×10^6
Ideal I _{sp} (s)	2900	3100	7300	8300


Easier-to-adjust ratio of “solute” to
“solvent” to modulate beam
strength.

Analysis of Technical Articles


Conferred Advantages

More stable


More modular



“Solute”



“Solvent”



Easier-to-adjust ratio of “solute” to “solvent” to modulate beam strength.


Analysis of Technical Article Excerpts

Conferred Advantages

More stable

More modular

Novel



Emitting charged nanoparticles rather than ions produced by them.

Property Control Position

Property Control Position

Patent: Use NIMs as the working fluid in electrospray, and on the LNIS method of emitting and accelerating multiply charged nanoparticles for thrust and beams.




Fig. 3 Experimental setup of the externally wetted LNIS

Copyright:

- Nanoparticle beam used for material deposition & propulsion.

Current IP: No patent application files and no electrospray sources using NIMs as the working fluid

- Electrospray Emitter Geometry
- Multiply charged nanoparticles extracted from liquid phase using strong electric fields

Market Application & Value Proposition

Market Application & Value Proposition

Space Propulsion

- High Thrust: Massive and multi charge nanoparticle
- Design for small satellite (CubeSats) and Scalable to large spacecraft
- Tunable Thrust by changing nanoparticle size and chemistry
- Reduce short circuit and lifetime
- Cost → Cheaper and more Scalable

Nanoparticle Beam Tools (Future Work)


- Surface modification and milling: Directly write nano milling, and patterns
- Material deposition: Control nanoparticle deposition for thin film
- Mass to charge ratio
- Research Lab and Semiconductor

Tech Readiness Level


Tech Readiness Level

- Established reproducible synthesis of NIMs
- Basic validation in laboratory environment
- **Surface Erosion tests:** Demonstrate controlled, narrow electrospray of ions
 - Low fidelity system (nm scale)
 - Emission precision → Propulsion precision

Nanoparticle Ionic Materials



Ionic Liquids



Technology Readiness Levels (TRL)

Actual system proven through successful mission operations.

9

Actual application of the technology in its final form and under mission conditions, such as those encountered in operational test and evaluation. Examples include using the system under operational mission conditions.

Actual system completed and qualified through test and demonstration.

8

Technology has been proven to work in its final form and under expected conditions. In almost all cases, this TRL represents the end of true system development. Examples include developmental test and evaluation of the system in its intended weapon system to determine if it meets design specifications.

System prototype demonstration in an operational environment.

7

Prototype near, or at, planned operational system. Represents a major step up from TRL 6, requiring demonstration of an actual system prototype in an operational environment such as an aircraft, vehicle, or space.

System/subsystem model or prototype demonstration in a relevant environment.

6

Representative model or prototype system, which is well beyond that of TRL 5, is tested in a relevant environment. Represents a major step up in a technology's demonstrated readiness.

Component and/or breadboard validation in relevant environment.

5

Fidelity of breadboard technology increases significantly. The basic technological components are integrated with reasonably realistic supporting elements so it can be tested in a simulated environment.

Component and/or breadboard validation in laboratory environment

4

Basic technological components are integrated to establish that they will work together. This is relatively "low fidelity" compared to the eventual system. Examples include integration of "ad hoc" hardware in the laboratory.

Analytical and experimental critical function and/or characteristic proof of concept.

3

Active research and development is initiated. This includes analytical studies and laboratory studies to physically validate analytical predictions of separate elements of the technology. Examples include components that are not yet integrated or representative.

Technology concept and/or application formulated.

2

Invention begins. Once basic principles are observed, practical applications can be invented. Applications are speculative and there may be no proof or detailed analysis to support the assumptions. Examples are limited to analytic studies.

Basic principles observed and reported

1

Lowest level of technology readiness. Scientific research begins to be translated into applied research and development. Examples might include paper studies of a technology's basic properties.

Ten-Point Tech Scoring

Ten Point Scoring Tool

	Categories	Score
1.	Detailed description of Invention and its Inventive features	5
2.	Potential/existing Quality of Property Control Position	3
3.	Market Relevance (solves economic/meaningful problem)	4
4.	Market Size & Characteristics	4
5.	Value Proposition/ Potential for Reasonable Business Model	5
6.	Potential for Significant Revenue Generation	4
7.	Stage of Development/ Technology Readiness	3
8.	Scale-up Feasibility	4
9.	Support, Funding & Resources	4
10.	Existing or Potential for Commercialization Partnerships	5
Total score:		41

- **Clear inventive features:** Nanoparticle ionic materials working fluid with greater charge density results in greater propulsion velocity
- Clear ties to satellite market
 - Expected to grow to \$108 billion by 2035
- ~\$100/kg for NIMs and ~\$1000/kg for ionic liquids
- 1-10pL/s fluid per emitter, 1000s of emitters per CubeSat
- Future work with Naval Research Lab
- Early stages of prototyping, low fidelity
- Overall Score: **41/50**

Tech Brief

Tech Brief, Distilled

- Summary of Invention:

A liquid nanoparticle solution is used as an ion source for microthrusters and ion microscopy.

- Features and benefits:

The LNIS system is more stable than contemporary ion sources, highly adjustable, and novel in its means of ion beam production.

- Opportunity presented:

The LNIS system represents a broadly applicable and novel ion beam generation method that possesses significant advantages over current methods.

Tech Brief, Distilled

- Stage of development:

Still experimental; tied to development of novel extruder trials in January.

- Business arrangements sought:

Already funded by DARPA / NSF, seeking partnerships with propulsion manufacturers (e.g. Busek, Ion-X, Revolution Space), propulsion customers (e.g. NASA JPL, DoD), and analytical companies (e.g. Hiden Analytical, Zeiss, Ionoptika).

- Contact information:

Stefan Bell, sb855@cornell.edu

Jatin Mukerji, jam834@cornell.edu

Questions?

References